

iMARK Accessories and Replacement Parts

- PK260P 3 Multi-Purpose Plastic Sheets—14³/₄"w x 23³/₄"l, 6 lbs
- PK260P12 12 Multi-Purpose Plastic Sheets—14³/₄"w x 23³/₄"l, 22 lbs
- PIMOUNT Dry Mount Accessory—Tray w/15"w x 20"l Base, 8 lbs
- 406106 Multi-Purpose Carrier Tray—15¹/₂"w x 22"l, 6 lbs
- PIPIN Retractable Pin Set Replacement—8 Pins, 1 lb

For complete list of accessories and replacement parts, visit www.GOiMARK.com

iMARK Die Cutter Repair Parts

- PI500283 Safety Guards—Set of Two
- PI500265 Crank Housing Assembly—Handle Side Assembly
- PI500260 Blank Housing Assembly—Non-Handle Side Assembly
- PI500270 Tray Guide Assembly—Tray Guides & Plastic Rollers in Side Panels
- PI500284 Top and Lower Roller Assembly—Middle Roller Parts
- PI500285 Handle Repair Kit—Crank Arm, Black Plastic Handle, Hardware, Die Pick



PRINT FINISHING SOLUTIONS

Cut Your Own Printed Sheets
Gain Total Control of Workflow
With the iMARK Die Cutter!

iMARK® Die Cutter Warranty

Your iMARK Die Cutter has a one-year warranty. If you experience defects in materials or workmanship, notify us at the address below. This warranty does not cover multi-purpose plastic sheets, die trays or steel-rule dies. Plastic sheets and trays are consumable parts that need to be replaced periodically, depending on use. iMARK steel-rule dies are guaranteed for 90 days.

**Owner's
Manual**



PRINT FINISHING SOLUTIONS

37007 South Oak Street • Kennewick, WA 99337
888-GOiMARK (888-464-6275) / 509-586-3659
Fax 800-369-1332 / 509-586-7774
info@GOiMARK.com • www.GOiMARK.com
©2008 iMARK

Item **109611I**

Dear iMARK Customer:

Congratulations on your purchase of the iMARK® Die Cutter! This is just the tool you need for complete workflow control, from image creation to print completion. Now you can cut a large quantity of portraits, business cards and other printed pieces in minutes, with or without radius corners. Easily transform your iMARK Die Cutter into a dry-mounting system by switching to the optional mounting system base and tray.

The instructions below will help you enjoy the full benefits of your new die cutter. Proper care of the die cutter will ensure many years of efficient use.

If you have further questions about operation or maintenance of the system, contact iMARK Customer Service at 888-GOiMARK (888-464-6275) or info@GOiMARK.com. Visit us at www.GOiMARK.com for additional information and product updates.

Operating Instructions

The iMARK Die Cutter comes with a multi-purpose carrier tray and plastic sheets. Standard, custom and specialty steel-rule dies and accessories are purchased separately. (NOTE: Connect tray guide assemblies and plastic handle before using machine. Complete instructions are included.)

Follow these cutting instructions for the highest quality prints and maximum efficiency:

- 1 Place die completely flat inside tray, **FOAM SIDE UP**. Place paper on die, printed side down, inside retractable registration pins. For dies without registration pins, simply place paper over blades.
- 2 Place cutting plastic on top of material to be cut, covering all registration pins. Slide tray with die, material and plastic sheet to meet middle roller. Turn handle to feed through machine.
- 3 Remove cut sheets and repeat process from the opposite direction.

View an online demo at www.GOiMARK.com

Tips for Efficient Cutting

- To avoid damaging registration pins, dies, tray and die cutter, all dies MUST be placed completely inside lip of tray, and plastic must cover the entire surface of die before cutting.
- Alternate cutting sides to extend the life of plastic sheets.
- Cutting one layer is recommended with portrait and business card dies, as well as any die that contains a creasing/scoring blade. However, paper varies tremendously in composition, fiber content and elasticity. Experiment to determine whether or not results are acceptable when cutting multiple layers.
- If handle is difficult to turn or die threatens to stick under middle roller, make sure die is flat in tray and you are not trying to cut too many layers at one time.

Automated Actions and Templates

Download optional actions and templates for standard portrait and business card layouts as well as iMARK photo cubes at www.GOiMARK.com. You can print instruction files if necessary. Actions and templates center images on the page to expedite the cutting process and increase production.

Beginners and novice users are encouraged to seek more advanced education before using iMARK action and template files. iMARK technical support is limited to specific use and does not include general software instruction, set up of operating systems or printer specifications. Technical questions directly related to iMARK actions should be directed to 888-GOiMARK (888-464-6275) or info@GOiMARK.com.

Adobe® Photoshop®

iMARK® offers actions for advanced users. Simply download files to your hard drive and load to Photoshop. Adobe offers Expert Technical Support at www.adobe.com.

Epson® Gemini®

iMARK® offers templates for standard portrait and business card sizes for skilled Gemini system users. Simply unzip files and upload to Gemini server. Technical support is available from the Epson Support Line or at www.epson.com.

iMARK Die Cutter Maintenance

The machine itself requires no maintenance. There are two consumable items with the iMARK Die Cutter: multi-purpose plastic sheets and carrier tray. Replacement cost of plastic sheets is relatively inexpensive, at pennies per wallet photo or business card. Three sheets of cutting plastic come with the system. We recommend plastic be replaced every 100 cuts, 50 cuts per side. The tray should be replaced if the metal shows signs of stretching (generally caused by using single format dies, one at a time). Clean punches with die pick if necessary.

- Always use the iMARK multi-purpose carrier tray when cutting or dry mounting with iMARK.
- Replace plastic sheets when cut edge of prints begins to deteriorate beyond satisfaction.
- Replace tray when steel shows signs of stretching or cutting pressure appears to have become uneven.
- iMARK Die Cutter repair parts are available or you can send your machine back to the factory for repair services.
- Order replacement or repair parts from iMARK at 888-GOiMARK (888-464-6275) or your dealer.